


# Alarm Interface Box (AIB)


Product No. PAS-623-AIB




# Summary



# Pinouts




# Illustration - Device connection








# Lights indication illustration




Beacon light


Alarm Interface Box





Lights Indication	Description
	No printing
	Fault warning
	Ink low warning
	Printing
	Printing with ink low warning

# Controller Setting





# Controller Setting



Ink warning :

Set up at 【 15 】 , it represents the printer will goes off alarm at ink remain less than 15%.

# Required Parts

PAS-623-AIB  
Trigger / Encoder signal Hub



Power connector is accessorized in the AIB

PLT-19-03  
RS232 Cable



FSP040-RHAN2-3P  
Power supply for Alarm Interface Box

Power cord  
PE-22-23 ; **Note for the plug style in order is needed**

DJ4510-700-45  
Beacon light



Power connector is accessorized in the beacon light



FSP040-RHAN2-3P  
Power supply for beacon light

Power cord  
PE-22-23 ; **Note for the plug style in order is needed**